

Push buttons with locator lamp – 10 A – 250 V AC

1-way	1-way with "bell" symbol	1-way with "light" symbol	1-way with "stairs" symbol

Screwless terminals



With cover frame

White	EPH1600121	EPH1700121	EPH1800121	EPH1900121
Cream	EPH1600123	–	–	–



Without cover frame

Anthracite	EPH1600171	EPH1700171	EPH1800171	–
Steel	EPH1600162	–	–	–
Aluminium	EPH1600161	–	–	–
Bronze	EPH1600169	–	–	–

Screw terminals



With cover frame

White	EPH1600321	EPH1700321	–	–
-------	------------	------------	---	---

Push button – 12 V AC with locator lamp and label holder

1-way



Screwless terminals



With cover frame

White	EPH1601521
-------	------------

Roller blind Push buttons – 10 A – 250 V AC



Screwless terminals



With cover frame

White	EPH1300121
Cream	EPH1300123



Without cover frame

White	EPH1370121
Cream	EPH1370123
Anthracite	EPH1300171
Steel	EPH1300162
Aluminium	EPH1300161
Bronze	EPH1300169

Screw terminals



With cover frame

White	EPH1300321
Cream	EPH1300323



Without cover frame

Anthracite	EPH1300371
Steel	EPH1300362
Aluminium	EPH1300361
Bronze	EPH1300369