





Asfora

Push buttons

Push buttons with locator lamp – 10 A – 250 V AC

1-way	1-way with "bell" symbol	1-way with "light" symbol	1-way with "stairs" symbol
			

Screwless terminals



With cover frame

☐ White	EPH1600121	EPH1700121	EPH1800121	EPH1900121
☐ Cream	EPH1600123	–	–	–



Without cover frame

☒ Anthracite	EPH1600171	EPH1700171	EPH1800171	–
☒ Steel	EPH1600162	–	–	–
☒ Aluminium	EPH1600161	–	–	–
☒ Bronze	EPH1600169	–	–	–

Screw terminals




With cover frame

☐ White	EPH1600321	EPH1700321	–	–
--------------------------------	------------	------------	---	---

Push button – 12 V AC with locator lamp and label holder

1-way




Screwless terminals



With cover frame

☐ White	EPH1601521
--------------------------------	------------

Roller blind Push buttons – 10 A – 250 V AC



Screwless terminals



With cover frame

☐ White	EPH1300121
☐ Cream	EPH1300123



Without cover frame

☐ White	EPH1370121
☐ Cream	EPH1370123
☒ Anthracite	EPH1300171
☒ Steel	EPH1300162
☒ Aluminium	EPH1300161
☒ Bronze	EPH1300169

Screw terminals



With cover frame

☐ White	EPH1300321
☐ Cream	EPH1300323



Without cover frame

☒ Anthracite	EPH1300371
☒ Steel	EPH1300362
☒ Aluminium	EPH1300361
☒ Bronze	EPH1300369